


Marlin®

CENTERFIRE

Lever Action Rifles

Model 1894



* Restricted availability—Part sent to qualified gunsmith only.
 ** Restricted availability—Parts installed at factory only.
 *** Non-restricted availability—Part may require some final fitting sanding or filing.

PARTS LIST CENTERFIRE LEVER ACTION RIFLES

For parts prices, call 1-800-544-8892 (8 A.M. to 4:30 P.M., Eastern Time, Weekdays)
 Be sure to mention gun serial number when ordering parts

ILL. NO.	PART NAME	ILL. NO.	PART NAME	ILL. NO.	PART NAME
**1	Barrel	27	Forearm Tip Tenon Screw (2)	52	Magazine Tube Plug
**2	Breech Bolt	28	Forearm Band	53	Magazine Tube Plug Screw
***3	Bullseye	29	Front Band Screw	54	Magazine Tube Spring
***4	Buttplate/Buttpad	30	Front Sight	55	Magazine Tube Stud
5	Buttplate/Buttpad Screw (2)	31	Front Sight Base	56	Rear Band
***6	Buttstock	32	Front Sight Base Screw (2)	57	Rear Band Screw
*7	Carrier Assembly	33	Front Sight Hood	58	Rear Sight Assembly
8	Carrier Screw	34	Front Sight Insert	59	Rear Sight Base
9	Ejector w/Spring	**35	Hammer	60	Rear Sight Elevator
10	Ejector Spring	36	Hammer Screw	61	Rear Sight Folding Leaf
***11	Extractor	37	Hammer Spring (Mainspring)	**62	Receiver
12	Extractor Retaining Pin	38	Hammer Spring Plate	**63	Safety Button Assembly
13	Extractor Spring	39	Hammer Spur Complete (Includes parts 40 and 41)	64	Scope Mount Dummy Screw (4)
***14	Extractor w/Spring	40	Hammer Spur Screw	*65	Sear
*15	Finger Lever	41	Hammer Spur Wrench	66	Swivel Stud, Rear
***16	Finger Lever Plunger	42	Hammer Strut	67	Tang Screw
17	Finger Lever Plunger Pin	43	Hammer Strut Pin	*68	Trigger
18	Finger Lever Plunger Spring	44	Loading Spring	69	Trigger and Sear Pin
19	Finger Lever Screw	45	Loading Spring Screw	**70	Trigger Guard Plate
20	Firing Pin, Front	*46	Locking Bolt	71	Trigger Guard Plate Latch Pin
21	Firing Pin, Rear	47	Magazine Tube	72	Trigger Guard Plate Screw
22	Firing Pin Retaining Pin (2)	48	Magazine Tube Band	73	Trigger Guard Plate Support Screw
23	Firing Pin Spring	49	Magazine Tube Band Pin	74	Trigger Safety Block
24	Forearm	50	Magazine Tube Assembly	75	Trigger Safety Block Pin
25	Forearm Tip	51	Magazine Tube Follower	76	Trigger Safety Block Spring
26	Forearm Tip Tenon			77	10 Shot Plug

ILL. NO.	PART NAME	1894 Part No.	1894FG Part No.	1894SS Part No.	1894C Part No.	1894CL Part No.	1894CBC (38) Part No.	1894CBC (45) Part No.	1894CB (45) Part No.	1894CB (357) Part No.	1894CB (44) Part No.	1894CB (32HRR) Part No.
**1	Barrel	114001	114037	114045	114000	114053	114024	114029	114003	114036	114035	114046
**2	Breech Bolt	114486	114586	114021	114386	114043	114386	114272	114272	114386	114486	114300
***3	Bullseye	320101	320101	320101	320101	320101	320101	320101	320101	320101	320101	320101
***4	Buttplate/Buttpad	417002	417002	417002	417002	320402	320402	320402	320402	320402	320402	320402
5	Buttplate/Buttpad Screw (2)	420590	420590	420590	420590	420590	420590	420590	420590	420590	420590	420590
**6	Buttstock	514013	501214	514013	514013	514113	514314	514113	514113	514314	514113	514314
*7	Carrier Assembly	514461	514461	514022	514561	514025	514562	514462	514461	514561	514461	514567
8	Carrier Screw	301190	301190	301001	301190	301190	301190	301190	301190	301190	301190	301190
9	Ejector w/Spring	501168	501168	501028	501168	501168	501100	501100	501168	501168	501168	501101
10	Ejector Spring	401294	401294	401294	401294	401294	401294	401294	401294	401294	401294	201101
***11	Extractor	214569	214569	214469	214569	214569	214569	214569	214569	214569	214569	214569
12	Extractor Retaining Pin	420598	420598	420598	420598	420598	420598	420598	420598	420598	420598	420598
13	Extractor Spring	314695	314695	314695	314695	314695	314695	314695	314695	314695	314695	314695
***14	Extractor w/Spring	514569	514569	514669	514569	514569	514569	514569	514569	514569	514569	514569
*15	Finger Lever	514170	514016	514270	514170	514170	514170	514171	514170	514170	514170	514170
***16	Finger Lever Plunger	214071	214071	214071	214071	214071	201071	201014	214071	214071	214071	214071
17	Finger Lever Plunger Pin	301197	301197	301009	301197	301197	301197	301197	301197	301197	301197	301197
18	Finger Lever Plunger Spring	401696	401696	401696	401696	401696	401696	401696	401696	401696	401696	401696
19	Finger Lever Screw	301192	301192	301002	301192	301192	301192	301192	301192	301192	301192	301192
20	Firing Pin, Front	414299	414299	414299	414299	414299	414299	414299	414299	414299	414299	414299
21	Firing Pin, Rear	401199	401199	401012	401199	401199	401199	401199	401199	401199	401199	401199
22	Firing Pin Retaining Pin (2)	420299	420299	401016	420299	420299	420299	420299	420299	420299	420299	420299
23	Firing Pin Spring	401295	401295	401295	401295	401295	401295	401295	401295	401295	401295	401295
24	Forearm	101127	101127	101127	114827	114527	114628	114628	114628	114628	114528	114628
25	Forearm Tip	501328	501328	514528	N/A	201128	214128	214128	214128	214128	214128	214128
26	Forearm Tip Tenon	220429	220429	220429	N/A	220429	220429	220429	220429	220429	220429	220429
27	Forearm Tip Tenon Screw (2)	320191	320191	101067	N/A	320191	320191	320191	320191	320191	320191	320191
28	Front Band	301233	301233	301010	314133	N/A	N/A	N/A	N/A	N/A	N/A	220100
29	Front Band Screw	301291	301291	301011	314190	N/A	N/A	N/A	N/A	N/A	N/A	N/A
30	Front Sight	N/A	N/A	N/A	N/A	414144	414144	414144	414144	414144	414144	414144
31	Front Sight Base	221239	221239	221239	221239	N/A	N/A	N/A	N/A	N/A	N/A	N/A
32	Front Sight Base Screw (2)	320991	320991	320991	320991	N/A	N/A	N/A	N/A	N/A	N/A	N/A
33	Front Sight Hood	320245	320245	320245	320245	N/A	N/A	N/A	N/A	N/A	N/A	N/A
34	Front Sight Insert	230744	230744	230744	216344	N/A	N/A	N/A	N/A	N/A	N/A	N/A
**35	Hammer	101273	101273	101038	101273	101273	101200	101200	101273	101273	101273	101273
36	Hammer Screw	301090	301090	301000	301090	301090	301090	301090	301090	301090	301090	301090
37	Hammer Spring (Mainspring)	420294	420294	420294	420294	420294	420009	420009	420294	420294	420294	420294
38	Hammer Spring Plate	320175	320175	320175	320175	320175	320175	320175	320175	320175	320175	320175
39	Hammer Spur Complete (Includes parts 40 and 41)	520377	520377	520377	520377	520377	N/A	N/A	520377	520377	520377	520377
40	Hammer Spur Screw	420193	420193	420193	420193	420193	N/A	N/A	420193	420193	420193	420193
41	Hammer Spur Wrench	420204	420204	420204	420204	420204	N/A	N/A	420204	420204	420204	420204
42	Hammer Strut	320174	320174	320174	320174	320174	320174	320174	320174	320174	320174	320174
43	Hammer Strut Pin	401397	401397	401397	401397	401397	401397	401397	401397	401397	401397	401397
44	Loading Spring	114594	114594	114694	114594	114594	114594	114594	114594	114594	114594	N/A
45	Loading Spring Screw	301591	301591	301006	301591	301591	301591	301591	301591	301591	301591	N/A
*46	Locking Bolt	114181	114181	114181	114181	114181	114025	114181	114181	114181	114181	114181
47	Magazine Tube	201022	201022	201002	214525	214022	214600	214625	214722	214600	214625	214602
48	Magazine Tube Band	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	220100
49	Magazine Tube Band Pin	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	420600
50	Magazine Tube Assembly	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	514600
51	Magazine Tube Follower	501045	501045	501045	514124	514124	514124	401424	501045	514124	501045	414520
52	Magazine Tube Plug	301225	301225	301004	314325	314025	314025	301425	301425	314025	301425	320100
53	Magazine Tube Plug Screw	301990	301990	301013	214490	301193	301193	301193	301193	301193	301193	N/A
54	Magazine Tube Spring	401395	401395	401395	414295	414595	401395	401395	401395	414595	401395	414595
55	Magazine Tube Stud	N/A	N/A	N/A	N/A	214425	214425	201125	201125	214425	201125	N/A
56	Rear Band	N/A	N/A	N/A	501521	N/A	N/A	N/A	N/A	N/A	N/A	N/A
57	Rear Band Screw	N/A	N/A	N/A	301590	N/A	N/A	N/A	N/A	N/A	N/A	N/A
58	Rear Sight Assembly	501342	501342	501342	501342	414000	414000	414000	414242	414000	414000	414000
59	Rear Sight Base	520241	520241	520241	520241	N/A	N/A	N/A	N/A	N/A	N/A	N/A
60	Rear Sight Elevator	320642	320241	320242	230142	N/A	714342	714342	714342	714342	714342	714342
61	Rear Sight Folding Leaf	201342	201342	214142	201342	N/A	N/A	N/A	N/A	N/A	N/A	N/A
**62	Receiver	114460	114460	114862	114360	114360	114500	114031	114760	114564	114760	114563
**63	Safety Button Assembly	599383	599383	599383	599383	599383	599383	599383	599383	599383	599383	599383
64	Scope Mount Dummy Screw (4)	320493	320493	320003	320493	320493	N/A	N/A	320493	320493	320493	320493
*65	Sear	201051	201051	201051	201051	201051	201051	201051	201051	201051	201051	201051
66	Swivel Stud, Rear	420793	420793	420002	420793	N/A	N/A	N/A	N/A	N/A	N/A	N/A
67	Tang Screw	314191	320391	320002	320391	320391	320391	320391	320391	320391	320391	320391
*68	Trigger	301643	301643	301743	301643	301643	301643	301643	301643	301643	301643	301643
69	Trigger and Sear Pin	401097	401097	401097	401097	401097	401097	401097	401097	401097	401097	401097
**70	Trigger Guard Plate	514158	514020	514358	514158	514158	514158	514158	514158	514158	514158	514158
71	Trigger Guard Plate Latch Pin	401099	401099	401008	401099	401099	401099	401099	401099	401099	401099	401099
72	Trigger Guard Plate Screw	301790	301790	301007	301790	301790	301790	301790	301790	301790	301790	301790
73	Trigger Guard Plate Support Screw	301490	301490	301005	301490	301490	301490	301490	301490	301490	301490	301490
74	Trigger Safety Block	301859	301859	301008	301859	301859	301859	301859	301859	301859	301859	301859
75	Trigger Safety Block Pin	420397	420397	420397	420397	420397	420397	420397	420397	420397	420397	420397
76	Trigger Safety Block Spring	401596	401596	401596	401596	401596	401596	401596	401596	401596	401596	401596
77	10 Shot Plug	N/A	N/A	N/A	N/A	N/A	414900	N/A	414824	414901	N/A	N/A