




PARTS LIST

<u>ITEM NO.</u>	<u>DESCRIPTION</u>	<u>ITEM NO.</u>	<u>DESCRIPTION</u>
01	STANDARD STOCK	24 *	RETAINING CLIP
02	THUMBHOLE STOCK	25 *	BOLT SPRING
03	ACTION SCREW	26 *	WASHER
04	MAGAZINE FOLLOWER	27 *	COCKING INDICATOR COLLAR
05	MAGAZINE SPRING	28 *	COCKING INDICATOR
06	MAGAZINE HOUSING	29 *	STRIKER CAM PIN
07	MAGAZINE BASE PLATE	30 *	STRIKER
08	BUTT PLATE	31 *	BOLT HANDLE
09	BUTT PLATE RETAINING SCREW	32 *	BOLT SHIM
10 *	SEAR	33 *	BOLT FRONT HOUSING
11 *	SEAR SPRING	34 *	FIRING PIN
12 *	TRIGGER	35 *	SHELL EXTRACTOR
13 *	TRIGGER SPRING	36 *	RECEIVER
14 *	EJECTOR	37 *	BARREL RETAINING PIN
15 *	TRIGGER HOUSING	38 *	BARREL
16 *	TRIGGER HOUSING SCREW	39	REAR SIGHT HEIGHT ADJUSTER
17 *	EJECTOR PIN	40	REAR SIGHT BASE
18 *	TRIGGER/SEAR/MAG RELEASE PIN	41	REAR SIGHT BLADE
19 *	MAGAZINE RELEASE	42	BLADE ADJUSTMENT SCREW
20 *	MAGAZINE RELEASE SPRING	43	REAR SIGHT SCREW
21 *	DETENT BALL	44	FRONT SIGHT
22 *	SAFETY BUTTON	45	FRONT SIGHT HOOD
23 *	BOLT REAR HOUSING	46	FRONT SIGHT SCREW

* Items on parts list are reserved for qualified gunsmiths or the authorized Product Service Center only.