

RUGER® 77/22® LR & MAG. & 77/17® HMR PARTS LIST

Design, prices and specifications subject to change without notice.

SPECIFY MODEL, CALIBER AND SERIAL NO. WHEN ORDERING


(See Exploded View on Page 34)

Key	Part Name	Key	Part Name
* 1	Barrel	25	Bolt Stop Plunger
1a	Barrel Retainer Screws, 2 Req'd	26	Striker Cross Pin
1b	Barrel Retainer V-Block	27	Rear Mounting Screw
† 2	Receiver	28	Front Mounting Screw
3	Pistol Grip Cap	29	Bolt Lock Plunger Retaining Ring
4	Recoil Pad	30	Safety Selector Detent
5	Recoil Pad Screws, 2 Req'd	31	Sear Pivot Pin
6	Pistol Grip Cap Screw	32	Magazine Latch Plunger
7	Grip Cap Medallion	33	Magazine Latch Lever Pivot Pin
8	Sling Swivel Screw	34	Striker
9	Sling Swivel Front Screw with Nut	35	Striker Spring
10	Stock	36	Magazine Well Liner
* 11	Sear	37	Firing Pin Cross Pin
12	Trigger Guard Assembly	38	Extractor Plunger, 2 Req'd
* 13	Bolt Handle	* 39	Firing Pin
* 14	Breech Block	40	Bolt Stop Plunger Spring
* 15	Trigger	41	Bolt Lock Plunger Spring
* 16	Extractor	42	Trigger/Sear Spring
* 17	Safety Selector	43	Extractor Spring
18	Magazine Latch Lever	44	Breech Block Retaining Pin
19	Safety Selector Retainer	45	Cartridge Support Spring
20	Bolt Lock Plunger	46	Magazine Latch Spring
21	Cocking Piece	47	Magazine Latch Plunger Spring
22	Bolt Sleeve	48	Magazine
23	Cartridge Support	49	Scope Rings
24	Bolt Stop		

* PARTS SO MARKED MUST BE FACTORY FIT

† Because the receiver is a serial numbered component, it is not sold as a separate component.

RUGER® 77/22® LR & MAG. & 77/17® HMR EXPLODED VIEW



**RUGER® 77/22® HORNET, 77/17® HORNET,
77/17® WSM, 77/44® & 77/357™
PARTS LIST**

Design, prices and specifications subject to change without notice.

SPECIFY MODEL, CALIBER AND SERIAL NO. WHEN ORDERING


(See Exploded Views on Pages 36 & 37)

Key	Part Name	Key	Part Name
* 1	Barrel	27	Rear Mounting Screw
† 2	Receiver	28	Front Mounting Screw
3	Pistol Grip Cap	29	Bolt Lock Plunger Retaining Ring
4	Recoil Pad	30	Safety Selector Detent
5	Recoil Pad Screws, 2 Req'd	31	Sear Pivot Pin
6	Pistol Grip Cap Screw	32	Magazine Latch Plunger
7	Grip Cap Medallion	33	Magazine Latch Lever Pivot Pin
8	Sling Swivel Screw	34	Striker
9	Sling Swivel Front Screw with Nut	35	Striker Spring
10	Stock	36	Magazine Well Liner
* 11	Sear	37	Firing Pin Cross Pin
12	Trigger Guard Assembly	38	Extractor Plunger
* 13	Bolt Handle	* 39	Firing Pin
* 14	Breech Block	40	Bolt Stop Plunger Spring
* 15	Trigger	41	Bolt Lock Plunger Spring
* 16	Extractor	42	Trigger/Sear Spring
* 17	Safety Selector	43	Extractor Spring
18	Magazine Latch Lever	44	Breech Block Retaining Pin
19	Safety Selector Retainer	46	Magazine Latch Spring
20	Bolt Lock Plunger	47	Magazine Latch Plunger Spring
21	Cocking Piece	48	Magazine
22	Bolt Sleeve	49	Scope Rings
24	Bolt Stop	50	Front Sight
25	Bolt Stop Plunger	51	Rear Sight
26	Striker Cross Pin		


* PARTS SO MARKED MUST BE FACTORY FIT

† Because the receiver is a serial numbered component, it is not sold as a separate component.

EXPLODED VIEW



RUGER® 77/44® & 77/357™
EXPLODED VIEW



SYNTHETIC STOCK

COMPONENT PARTS LIST & EXPLODED VIEW

Key	Part Name
3	Pistol Grip Cap
4	Recoil Pad
5	Recoil Pad Screws, 2 Req'd
6	Pistol Grip Cap Screw
7	Grip Cap Medallion
8	Sling Swivel Screw
9	Sling Swivel Front Screw with Nut
10	Stock
28	Front Mounting Screw – (77/44 <i>only</i>)

