

# RUGER AMERICAN® RIFLE

## GENERATION II

### PARTS LIST

Design, prices and specifications subject to change without notice.

**SPECIFY MODEL, CALIBER AND SERIAL NO. WHEN ORDERING**

(See Exploded Views Pages 49 - 52)

| Key  | Part Name                                                                                                 |
|------|-----------------------------------------------------------------------------------------------------------|
| * 1  | <b>Firing Pin / Bolt Assembly – Complete</b><br><b>Includes Key Nos. 2 - 15 (See Exploded View p. 50)</b> |
| 2    | Bolt Shroud                                                                                               |
| 3    | Firing Pin Back                                                                                           |
| 4    | Firing Pin Spring Stop                                                                                    |
| 5    | Firing Pin Spring                                                                                         |
| 6    | Firing Pin                                                                                                |
| * 7  | Bolt Body                                                                                                 |
| 8    | Bolt Handle                                                                                               |
| 9    | Bolt Knob                                                                                                 |
| 10   | Ejector Spring                                                                                            |
| 11   | Ejector Plunger                                                                                           |
| 12   | Extractor                                                                                                 |
| 13   | Extractor Ball                                                                                            |
| 14   | Extractor Spring                                                                                          |
| 15   | Ejector/Firing Pin Back Pin, 2 Req'd                                                                      |
| 16   | <b>Bolt Stop Lever</b>                                                                                    |
| 17   | <b>Bolt Stop Spring</b>                                                                                   |
| 18   | <b>Bolt Stop Pin</b>                                                                                      |
| 19   | <b>Scope Base</b>                                                                                         |
| 20   | <b>Scope Base Screws, 4 Req'd</b>                                                                         |
| † 21 | <b>Receiver</b>                                                                                           |
| * 22 | <b>Barrel Nut</b>                                                                                         |
| * 23 | <b>Barrel</b>                                                                                             |
| 24   | <b>Muzzle Device</b>                                                                                      |
| * 25 | <b>Trigger Assembly – Complete</b><br><b>Includes Key Nos. 26 - 45 (See Exploded View p. 51)</b>          |
| 26   | Safety Button                                                                                             |
| * 27 | Sear                                                                                                      |
| 28   | Sear Spring                                                                                               |
| * 29 | Safety Link                                                                                               |
| 30   | Trigger Sear Pin, 2 Req'd                                                                                 |
| * 31 | Trigger Block Pin                                                                                         |
| * 32 | Safety Shaft                                                                                              |
| 33   | Safety Plunger                                                                                            |
| 34   | Safety Spring                                                                                             |

\* Parts so marked must be factory fit.


† The receiver is a serial-numbered part and is not offered for sale.

| <b>Key</b> | <b>Part Name</b>                                           |
|------------|------------------------------------------------------------|
| 35         | Trigger Spring                                             |
| 36         | Trigger Adjustment Screw                                   |
| * 37       | Trigger                                                    |
| 38         | Trigger Release Spring                                     |
| 39         | Trigger Release Pin                                        |
| * 40       | Trigger Release                                            |
| 41         | Safety Shaft E-Clip                                        |
| 42         | Trigger Block Pin E-Clip                                   |
| 43         | Trigger Sear Pin E-Clip, 2 Req'd                           |
| 44         | Sear Stop Pin                                              |
| * 45       | Trigger Housing                                            |
| 46         | <b>Trigger Housing Pin, 2 Req'd</b>                        |
| 47         | <b>Stock Assembly – Complete</b>                           |
|            | <b>Includes Key Nos. 48 - 64 (See Exploded View p. 52)</b> |
| 48         | Recoil Pad                                                 |
| 49         | Length-of-Pull Spacer                                      |
| 50         | Comb                                                       |
| 51         | Stock                                                      |
| 52         | Length-of-Pull Nut                                         |
| 53         | Length-of-Pull Spacer Washer                               |
| 54         | Rear Swivel Stud Nut                                       |
| 55         | Rear Swivel Stud                                           |
| 56         | Rear Swivel Stud Standoff                                  |
| 57         | Length of Pull Spacer Bolt                                 |
| 58         | <b>Magazine Well</b>                                       |
| 59         | Magazine Button – AR-Style Magazine Well                   |
|            | Magazine Latch – Mini Thirty & AI-Style Magazine Well      |
| 60         | Magazine Latch Spring                                      |
| 61         | Magazine Latch Pin                                         |
| 62         | <b>Action Screws, 2 Req'd</b>                              |
| 63         | <b>Magazine</b>                                            |


\* Parts so marked must be factory fit.

**RUGER AMERICAN® RIFLE**  
**GENERATION II**  
**EXPLODED VIEW**


49




**RUGER AMERICAN® RIFLE**  
**GENERATION II**  
**FIRING PIN / BOLT ASSEMBLY**



**RUGER AMERICAN® RIFLE**  
**GENERATION II**  
**TRIGGER ASSEMBLY**



**RUGER AMERICAN® RIFLE  
GENERATION II  
STOCK ASSEMBLY**



**AR-Style Magazine Well Assembly**

**Mini Thirty® Magazine Well Assembly**

**Flush Magazine Well Assembly**

# RUGER AMERICAN® RIFLE MAGAZINES

## Flush-Fit Magazines: Short-Action



Rotary



Flush-Fit



450 Bushmaster

## Flush-Fit Magazines: Long-Action



Rotary



Magnum 3-rd

NOTE: This page depicts magazines frequently utilized in the Ruger American® Rifle. Some models may ship with a magazine or configuration not pictured.

## AI-Style Magazines: Short-Action



.308 3-rd



.223 10-rd

## AR-Style Magazines



5-rd Box



10-rd Box

## Mini Thirty® Magazine



5-rd