

RUGER® MAX-9™ PISTOL

PARTS LIST

Design, prices and specifications subject to change without notice.
SPECIFY MODEL, CALIBER, AND SERIAL NO. WHEN ORDERING
 (See Exploded View on Page 45)

Key No.	Part Name
1	Grip Frame
2	Magazine Latch
3	Magazine Latch Spring
4	Grip Cap
* 5	Slide
6	Optics Plate Cover
7	Optics Cover Screw, 2 Req'd
8	Rear Sight
9	Blocker Keeper
* 10	Striker Blocker
11	Blocker Spring, 2 Req'd
12	Striker Cover
* 13	Striker
14	Striker Sleeve
15	Striker Spring
16	Striker Keeper Cup, 2 Req'd
17	Extractor Pivot Pin
18	Extractor
19	Extractor Spring
20	Extractor Booster Spring, 2 Req'd
21	Front Sight
22	Locator Pin, 2 Req'd
† 23	Frame Insert
24	Trigger Pivot
25	Outer Trigger
26	Inner Trigger
27	Inner Trigger Spring
28	Inner Trigger Pin
29	Trigger Pivot Pin
30	Trigger Bar Spring
* 31	Trigger Bar
32	Slide Stop
* 33	Manual Safety

† The Frame Insert is a serial-numbered component and is defined as a “firearm” by Federal Law and is not sold as a separate component.

* PARTS SO MARKED MUST BE FACTORY FIT

Key No.	Part Name
34	Manual Safety Spring
35	Sear Pivot Pin
* 36	Sear
* 37	Blocker Lifter
38	Sear Spring
39	Ejector
40	Takedown Plate
41	Slide Stop Spring
* 42	Barrel
43	Frame Insert Pin
44	Magazine Assembly, 10-rd
45	Takedown Pin
46	Guide Rod Assembly
47	Magazine Base Finger Extension
48	Magazine Assembly, 12-rd

* PARTS SO MARKED MUST BE FACTORY FIT

RUGER® MAX-9™ PISTOL

EXPLODED VIEW

