

RUGER® SFAR™

PARTS LIST

Design, prices and specifications subject to change without notice.

SPECIFY MODEL, CALIBER, AND SERIAL NO. WHEN ORDERING

(See Exploded Views on Pages 51 - 54)

Key	Part Name
1	Charging Handle
2	Lower Receiver Assembly – Complete Includes Key Nos. 3 - 39 (See Exploded View p. 52)
3	Buttstock Assembly
	3a Buttstock
	3b Receiver Extension
4	Buffer Spring
5	Receiver Extension Nut
6	Buffer
7	Receiver Endplate
8	Buffer Retainer Spring
9	Buffer Retainer Plunger
* 10	Selector Switch
11	Takedown Detent Spring
12	Takedown Detent, 2 Req'd
13	Takedown Pin
14	Selector Detent
15	Selector Detent Spring
16	Pistol Grip Screw
17	Grip Screw Washer
18	Pistol Grip
19	Trigger Guard Roll Pin, 2 Req'd
20	Magazine Catch Button
21	Trigger Guard
22	Magazine Catch Spring
23	Pivot Pin
24	Trigger Pin/ Hammer Pin, 2 Req'd
* 25	Hammer
26	Hammer Spring
* 27	Disconnecter
28	Disconnecter Spring
* 29	Trigger
30	Trigger Spring
31	Bolt Catch
32	Bolt Catch Roll Pin
33	Magazine Catch Assembly
34	Bolt Catch Plunger
35	Bolt Catch Plunger Spring
† 36	Lower Receiver


† The receiver is a serial-numbered part and is not separately offered for sale.


* Parts so marked must be factory fit.

Key	Part Name
37	Takedown Detent Spring
38	Regulator Adjustment Wrench
39	Wrench Storage Insert
40	Upper Receiver Assembly – Complete
	Includes Key Nos. 41 - 53 (See Exploded View p. 53)
41	Forward Assist Assembly
42	Forward Assist Spring
43	Upper Receiver
44	Forward Assist Roll Pin
45	Handguard Screw, 2 Req'd
46	Handguard
47	Ejection Port Cover
48	Ejection Port Cover Spring
49	Ejection Port Cover Retaining Clip
50	Ejection Port Cover Rod
51	Barrel Nut
* 52	Barrel Assembly
53	Adjustable Gas Block Assembly – Complete
	Includes Key Nos. 54 - 60 (See Exploded View p. 54)
54	Gas Block
55	Regulator
56	Detent
57	Detent Spring
58	Gas Tube
59	Gas Block Pin
60	Gas Block Set Screw, 2 Req'd
61	Bolt Carrier Assembly – Complete
	Includes Key Nos. 62 - 76 (See Exploded View p. 54)
62	Firing Pin
63	Bolt Carrier
64	Gas Key Screw
65	Cotter Pin
66	Gas Key
67	Cam Pin
68	Gas Ring, 3 Req'd
* 69	Bolt
70	Extractor
71	Extractor Buffer Spring
72	Extractor Spring
73	Extractor Pin
74	Ejector Pin
75	Ejector Spring, 2 Req'd
76	Ejector
77	Muzzle Brake

* Parts so marked must be factory fit.


RUGER® SFAR™
EXPLODED VIEW






RUGER® SFAR™
LOWER RECEIVER ASSEMBLY

RUGER® SFAR™
UPPER RECEIVER ASSEMBLY



RUGER® SFAR™
GAS BLOCK ASSEMBLY



RUGER® SFAR™
BOLT CARRIER ASSEMBLY

